



UNO

ON

AREF GND 13 12 ~11 ~10 ~9 8 7 6 ~5 ~4 3 ~2 TX-1 RX-0  
DIGITAL (PWM ~)

TX RX

IOREF RESET 3.3V 5V GND GND Vin  
POWER

ANALOG IN

A0 A1 A2 A3 A4 A5